

REFLECTA UNDER-SLAB

GI-USI

REFLECTA™

REFLECTIVE DAMP PROOFING MEMBRANE

Installation Guide

Reflecta Under-Slab™
Document Version: Dec 2025



INSTALLATION

- STEP 1** The ground must be prepared prior to laying Reflecta Under-Slab™, including all formwork, ensure the ground is free of sharp objects to prevent punctures.
- STEP 2** Roll out Reflecta Under-Slab™ to fully cover the ground surface under the slab and extend up to the slab finished floor level (ensuring foil side is up).
- STEP 3** Overlap joins by a minimum of 100mm to ensure a continuous barrier. Tape all joins and seals around services.
- STEP 4** Instore pods and pour concrete to manufacturers specifications.

DISCLAIMER

The product information included in this publication is provided in good faith in order to ensure the optimum performance of this product. However, no warranty is given or implied with respect to this information or the product itself regarding the product's suitability for any particular purpose, as factors outside our knowledge and control may affect its use. The usage of this and other building membranes will affect moisture migration in the building element. The purchaser is responsible for independently determining the sustainability of the product for the intended purpose. GI Building Services Pty Ltd reserves the right to amend product specifications without prior notice. Information provided is considered to be true and correct at the time of publication.

This product is not suitable whenever a non-combustible product is required.

- NOTE** Keep reflective surface free of debris to safeguard a high thermal performance.

